

# QuickBOLT

# 17667DF

DUAL FLASHED QB1  
WITH MICROFLASHING® & MINIFLASHING®  
**NO SEALANT  
REQUIRED**



Simply install the Low Profile QB1 with Microflashing®, then slide the Miniflashing® under the shingles and use the nut to secure the Miniflashing® and L-Foot.

## NO REMOVING NAILS OR STAPLES

PERMIT PACKET &  
INSTALL VIDEO  
AVAILABLE ONLINE

[WWW.QUICKBOLT.COM](http://WWW.QUICKBOLT.COM)  
**(844) 671-6045**